



TABLET ZELIG PAD 410L

XZPAD410L Rev. 2.0

XZPAD410L Rev. 3.0

PROCEDURA DI RIPRISTINO

La procedura illustrata di seguito consente di ripristinare il tablet alle condizioni di fabbrica.

ATTENZIONE!

La presente procedura di ripristino cancella tutti i dati presenti sul tablet.

Ripristino del tablet

E' ora possibile procedere al ripristino del tablet secondo i punti indicati di seguito.

1. A tablet spento tenere premuti per almeno 5 secondi il tasto "Power" ed il tasto "Indietro".
2. Utilizzare il tasto "Indietro" per spostarsi tra le voci selezionabili del menù ed il tasto "Power" per selezionare.
3. Spostarsi con la selezione sulla voce "WIPE DATA/FACTORY RESET" e premere il tasto "Power".
4. Alla schermata successiva spostarsi sulla voce "YES -- Delete all user data" e premere il tasto "Power".
5. Attendere alcuni secondi per il termine del reset.
6. Terminata l'operazione di reset spostarsi sulla voce "REBOOT SYSTEM NOW" e premere il tasto "Power".
7. Il tablet si riavvierà come alla prima accensione.

Nota Importante

Hamlet declina ogni responsabilità per l'eventuale perdita di dati. Per prevenire possibili perdite di dati, si consiglia vivamente di effettuare almeno una copia dei dati e di conservarla ad esempio su un'unità disco esterna o su un supporto di archiviazione rimovibile.

RESTORE PROCEDURE

The following procedure allows you to restore the tablet to factory settings.

WARNING!

This recovery process deletes all the data on your tablet.

Restoring the tablet

It is now possible to restore the tablet according to the following points.

1. With the tablet turned off press and hold the “Power” and “Back” buttons for at least 5 seconds.
2. Use the “Back“ button to move between menu items and the “Power” button to select.
3. Select the “WIPE DATA/FACTORY RESET” menu item then press “Power” button.
4. At the following screen select “YES -- Delete all user data” and press the “Power” button.
5. Wait for few seconds until reset procedure is completed.
6. Once the reset procedure is completed, select the “REBOOT SYSTEM NOW” menu item and press the “Power” button to confirm.
7. The tablet will reboot with factory default settings.

Important Note

Hamlet disclaims any liability for any loss of data. To prevent possible data loss, it is highly recommended that you make a copy of the data and store it on an external hard drive or on a removable storage media.