




10/100 LAN CARD
Fast Ethernet PCI Card



USER MANUAL
HN360TX_FC

www.hamletcom.com

Dear Customer,
thanks for choosing an Hamlet product. Please carefully follow the instructions for its use and maintenance and, once this item has run its life span, we kindly ask You to dispose of it in an environmentally friendly way, by putting it in the separate bins for electrical/electronic waste, or to bring it back to your retailer who will collect it for free.



We inform You this product is manufactured with materials and components in compliance with RoHS Directive 2002/95/CE; with WEEE Directive 2003/96/CE, Italian Legislative Decree 2005/151 and EMC Directive 89/336/EEC for the following standards:
EN55022: 1998 + A1: 2000 + A2: 2003
EN55024: 1998 + A1: 2001 + A2: 2003



The complete CE declaration of conformity of the product can be obtained by contacting Hamlet at info@hamletcom.com.

The information on the importer for your country can be found in the “About Us” section of the Hamlet website at www.hamletcom.com.

Trademarks and changes

All trademarks and company names mentioned in this manual are used for description purpose only and remain property of their respective owners.

The material in this document is for information only and subject to change without notice.

Introduction

The Hamlet 10/100Mbps LAN card is a PCI network adapter with a auto-negotiation 10/100 RJ-45 connector and support for half and full-duplex operation mode.

System Requirements

- Windows 98SE/2000/XP/Vista/7
- CD-Rom drive
- 1 free PCI Slot

Package Contents

- 10/100 LAN Card
- User Manual
- CD Driver

Caution!

Before handling and installing your Hamlet PCI Card, ensure that you have properly grounded yourself. Electrostatic discharge can quickly and easily damage your component or your computer.

Hardware installation

1. Turn off your computer and disconnect the power cord and all external peripheral devices and cables.
2. Remove your computer's cover. Please refer to your computer's manual for specific details.
3. Once you have removed the cover, locate the PCI slots on the motherboard. If necessary, you may need to remove the expansion slot cover, and you may also need to remove any add-in boards which block access to the PCI slots.
4. Take the Hamlet PCI Card out of its anti-static package and push the card into the empty PCI card slot.
Important note: There is only way to mount the card, so if you are having problems inserting the card into the PCI slot, make sure that it is oriented correctly. Be sure that the gold contact pins of the PCI card are seated completely inside your computer's PCI slot.
5. Once the PCI card is seated correctly, tighten with a screw. If necessary, replace any add-in boards that you removed at 3.
6. Now you are ready to put the computer's cover back on and reconnect all of your external peripheral devices and cables.

Driver installation

There are no drivers to install for Windows XP and above. The Hamlet 10/100 LAN Card is installed automatically. The drivers for operating systems earlier than Windows XP are on the CD supplied with the product.