

Hamlet

WIRELESS SMART TV KEYBOARD
2.4GHz Wireless RF Keyboard + Touchpad
for Smart TV, Tablet PC, Smartphone and PC



USER MANUAL
XRFKEYPADTV_VN

www.hamletcom.com

Dear Customer,

thanks for choosing an Hamlet product. Please carefully follow the instructions for its use and maintenance and, once this item has run its life span, we kindly ask You to dispose of it in an environmentally friendly way, by putting it in the separate bins for electrical/electronic waste, or to bring it back to your retailer who will collect it for free.



We inform You this product is manufactured with materials and components in compliance with RoHS Directive 2011/65/EU, WEEE Directive 2002/96/CE, 2003/108/CE Italian Legislative Decree 2005/151 and EMC 2004/108/EC, R&TTE 1999/5/EC, LVD 2006/95/EC Directives for the following standards:

EN 60950-1: 2006 + A11: 2009 + A1: 2010 + A12: 2011

ETSI EN 300 440-1 v1.6.1

ETSI EN 300 440-2 v1.4.1

ETSI EN 301 489-1 v1.9.2

ETSI EN 301 489-3 v1.6.1

EN 62479: 2010



CE Mark Warning

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

The complete CE declaration of conformity of the product can be obtained by contacting Hamlet at info@hamletcom.com specifying the product code and the documentation.

The information on the importer for your country are available in the "About us" section of the Hamlet website at www.hamletcom.com.

Trademarks and changes

All trademarks and company names mentioned in this manual are used for description purpose only and remain property of their respective owners.

The material in this document is for information only and subject to change without notice. Specifications and appearance of the product are subject to change without prior notice.

Introduction

Hamlet Wireless Smart TV Keyboard is a compact keyboard with a touchpad and two buttons for convenient control of the mouse able to communicate wirelessly thanks to the 2.4GHz RF wireless technology. It is the ideal solution to comfortably control devices such as Smart TV, Computer, Tablet PCs and Smartphones. The keyboard works with two common AAA batteries that provide extended use of the device and includes a nano USB receiver for the wireless connection.

Features

- 2.4GHz wireless RF technology with 10 m coverage
- Keyboard with Italian QWERTY layout
- Nano USB receiver
- Built-in touchpad
- Multimedia keys for volume adjusting and playback control
- ON/OFF power switch
- Dimensions: 282 x 118 x 17 mm
- Weight: 220 g

Package content

- Wireless keyboard with touchpad
- Nano USB wireless receiver
- 2x AAA battery
- User manual

System requirements

- USB port
- Smart TV, Computer, Tablet PC, Smartphone
- Compatible with Windows, Mac and Android OS

Keyboard layout

The keyboard has an Italian QWERTY layout with 80 keys and integrates a touchpad for pointer control and two mouse buttons. There are also 4 multimedia keys that allow you to control some functions of the connected device such as volume adjusting or audio/video file playback.



Nano USB receiver

The keyboard comes with a USB receiver for wireless connection to the device you want to control.

The USB receiver is housed in the cover of the battery compartment on the back of the keyboard.

LED indicators



Low Battery Indicator



Caps Lock Indicator



Scroll Lock Indicator

Installation and use

The keyboard setup is quick and easy and does not require the installation of any drivers.

1. Open the battery compartment located under the keyboard and insert the two AAA batteries according to the polarity signs marked inside the battery compartment.
2. Turn on the keyboard using the switch on the back of the keyboard.
3. Insert the USB receiver into an available USB port on the device you want to control.
4. The system automatically recognizes and installs the receiver.


The wireless keyboard is now ready for use.

Using the touchpad

To move the pointer on the screen, slide your finger across the touchpad surface.





To scroll the contents up and down, slide two fingers up or down on the touchpad surface.

Use the left and right touchpad buttons as you would the corresponding buttons on an external mouse.



Multimedia keys

The multimedia keys allow to control some function of the connected device directly from the keyboard.

	Play/Pause. Play or Pause a multimedia file (audio or video).
	Mute. Press this key to turn off the audio of the connected device.
	Increase volume. Press/Hold down this key to increase the volume.
	Decrease volume. Press/Hold down this key to decrease the volume.

Important Note

The multimedia keys may work on some devices only.

Function keys

The **Fn** button located in the bottom left of the keyboard allows you to activate the function keys identified by the characters and symbols printed in blue.

Hold down the **Fn** key on the keyboard and press the desired function key to type the character or activate the function.

Power saving mode

After 5 minutes of inactivity, the keyboard will enter sleep mode. Press any key to activate the keyboard.

If you do not plan to use the keyboard for a prolonged period of time, we recommend to turn it off and disconnect the USB receiver from the device in which it is inserted.